# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| ACER | AcerNote 330T | Green(19V) | D |
| ACER | AcerNote 350, 352, 355, 356, 358 | Green(19V) | D |
| ACER | AcerNote 361 | Green(19V) | D |
| ACER | AcerNote 367D, 367T, 368D | Green(19V) | C |
| ACER | AcerNote 370, 370C, 374 Series | Green(19V) | D |
| ACER | AcerNote 390-395 Series | Green(19V) | C |
| ACER | AcerNote 850C Series | Green(19V) | D |
| ACER | AcerNote 950, 950C, 950CX | Black(20V) | C |
| ACER | AcerNote Light 350, 352, 355, 356, 358, 359, 360 | Green(19V) | D |
| ACER | AcerNote Light 370-373 Series | Green(19V) | D |
| ACER | AcerNote Light 380, P100 | Green(19V) | D |
| ACER | Anywhere 1100LX, 1120LX | Green(19V) | C |
| ACER | Aspire 1200 | Black(20V) | D |
| ACER | Aspire 1300, 1300XC, 1302XC Series | Green(19V) | D |
| ACER | Aspire 1350, 1353LC, 1355LC, 1355LCi, 1356LCi Series | Green(19V) | D |
| ACER | Aspire 1400, 1400XC, 1400XV, 1403, 1403LC Series | Green(19V) | D |
| ACER | Aspire 2000, 2000WLCi, 2000WLMi Series | Green(19V) | D |
| ACER | Aspire 2001, 2001LCi, 2001WLCi, 2001WLMi Series | Green(19V) | D |
| ACER | Aspire 2002, 2002LCi, 2002LMi Series | Green(19V) | D |
| ACER | Aspire 2003, 2003LMi, 2003WLMi Series | Green(19V) | D |
| ACER | Aspire 2010, 2012, 2012WLCi, 2012WLCi-XPH, 2012WLCi-XPP, 2012WLMi, 2012WLMi-XPP, 2012WMCi Series | Green(19V) | D |
| ACER | Aspire 2020,2023, 2023WLCi, 2023WLMi, 2023WMCi Series | Green(19V) | D |
| ACER | Aspire 2025, 2025WLMi Series | Green(19V) | D |
| ACER | Aspire 2026, 2026WLMi, 2026WMC Series | Green(19V) | D |
| ACER | Aspire 4310, 4520, 4520G, 4710G, 4720, 4720G, 4920G | Green(19V) | D |
| ACER | Aspire 5051A, 5053, 5054, 5610A, 5720G, 5580, 5583 | Green(19V) | D |
| ACER | Extensa 350 Series | Green(19V) | C |
| ACER | Extensa 355 Series | Green(19V) | D |
| ACER | Extensa 365 Series | Green(19V) | C |
| ACER | Extensa 366, 366D | Green(19V) | C |
| ACER | Extensa 367 Series, 367D/T | Green(19V) | C |
| ACER | Extensa 368 Series, 368D | Green(19V) | C |
| ACER | Extensa 370 Series | Green(19V) | C |
| ACER | Extensa 390-395 Series | Green(19V) | C |
| ACER | Extensa 450, 455 Series | Green(19V) | D |
| ACER | Extensa 500, 501, 502, 503, 505 Series | Green(19V) | D |
| ACER | Extensa 510, 515, 524 Series | Green(19V) | D |
| ACER | Extensa 550, 560, 570 Series | Green(19V) | C |
| ACER | Extensa 600, 605, 610, 616, 620 Series | Green(19V) | D |
| ACER | Extensa 650, 660, 670, 690 Series | Green(19V) | D |
| ACER | Extensa 700-712 Series | Green(19V) | D |
| ACER | Extensa 900 Series | Green(19V) | C |
| ACER | Extensa Ess3-391T | Green(19V) | C |
| ACER | Ferrairi 3000, 3200 series | Green(19V) | C |
| ACER | Tablet TMC104TCI | Black(20V) | D |
| ACER | Tablet TMC110TCi | Black(20V) | D |
| ACER | Tablet TMC110Ti | Black(20V) | D |
| ACER | TravelMate 200-213 Series | Green(19V) | D |
| ACER | TravelMate 220-222 Series | Green(19V) | D |
| ACER | TravelMate 230, 230X, 230XC, 230XV, 230XV Pro Series | Green(19V) | D |
| ACER | TravelMate 233, 233LC, 233X, 233XV, 233XVi, 234, 234LC Series | Green(19V) | D |
| ACER | TravelMate 260, 261, 261XC, 261XV Series | Green(19V) | D |
| ACER | TravelMate 270, 270XV, 272, 272LC, 272XV, 272XVi, 273, 273XV Series | Green(19V) | D |
| ACER | TravelMate 280, 281XC, 283, 283LC, 283LCi, 283XV, 283XVi Series | Green(19V) | D |
| ACER | TravelMate 290, 290ATI, 290E, 290LCi, 290LCi Home, 290LCi Pro, 290LMi Series | Green(19V) | D |
| ACER | TravelMate 290XCi, 290Xi, 290XMi, 290Xvi Series | Green(19V) | D |
| ACER | TravelMate 291LCi, 291LMi Series | Green(19V) | D |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| ACER | TravelMate 292, 292ELCi, 292ELMi, 292EXCi, 292LCi, 292LMi, 292Xci Series | **Green(19V)** | **D** |
| ACER | TravelMate 310-314 Series | **Green(19V)** | **D** |
| ACER | TravelMate 330-333 Series | **Green(19V)** | **D** |
| ACER | TravelMate 340-347 Series | **Green(19V)** | **D** |
| ACER | TravelMate 350-354 Series | **Green(19V)** | **D** |
| ACER | TravelMate 360-364 Series | **Green(19V)** | **D** |
| ACER | TravelMate 4000M, 4000WinDX4 | **Green(19V)** | **C** |
| ACER | TravelMate 420, 430 series | **Green(19V)** | **C** |
| ACER | TravelMate 4320 | **Green(19V)** | **D** |
| ACER | TravelMate 505-508 Series | **Green(19V)** | **D** |
| ACER | TravelMate 510 Series | **Green(19V)** | **D** |
| ACER | TravelMate 512DX, 512T | **Blue(16V)** | **C** |
| ACER | TravelMate 513-517 Series | **Green(19V)** | **D** |
| ACER | TravelMate 520, 520iT, 521, 521TE, 521TEV, 521TXV Series | **Green(19V)** | **D** |
| ACER | TravelMate 524, 524TE, 524TXV, 525, 525TE, 525TX, 525TXV Series | **Green(19V)** | **D** |
| ACER | TravelMate 6000, 6003, 6003LCi, 6003LMi Series | **Green(19V)** | **D** |
| ACER | TravelMate 600-604 Series | **Green(19V)** | **D** |
| ACER | TravelMate 610-614 Series | **Green(19V)** | **D** |
| ACER | TravelMate 620-623 Series | **Green(19V)** | **D** |
| ACER | TravelMate 6231, 6252, 6291, 6292 | **Green(19V)** | **D** |
| ACER | TravelMate 630-633 Series | **Green(19V)** | **D** |
| ACER | TravelMate 650, 660, 710 Series | **Green(19V)** | **D** |
| ACER | TravelMate 720-723 Series | **Green(19V)** | **D** |
| ACER | TravelMate 730-739 Series | **Green(19V)** | **D** |
| ACER | TravelMate 740-744 Series | **Green(19V)** | **D** |
| ACER | TravelMate 800 Series | **Green(19V)** | **D** |
| ACER | TravelMate 8000, 8002, 8002LCi, 8002LCib Series | **Green(19V)** | **D** |
| ACER | TravelMate 8003, 8003LCi, 8003LMi, 8003LMib Series | **Green(19V)** | **D** |
| ACER | TravelMate 8004, 8004LMi Series | **Green(19V)** | **D** |
| ACER | TravelMate 8005, 8005LMi, 8005LMib Series | **Green(19V)** | **D** |
| ACER | TravelMate 8006, 8006LMi Series | **Green(19V)** | **D** |
| ACER | TravelMate C100, C102, C102T, C102TCi, C102Ti, C104, C104CTi, C104Ti Tablet PC Series | **Green(19V)** | **D** |
| ACER | TravelMate C110, C110CTi, C110Ti, C110TCi, C111, C111CTi, C111TCi, C111Ti, C111TCib Tablet PC Series | **Green(19V)** | **D** |
| ACER | TravelMate C300, C300XCi Tablet PC Series | **Green(19V)** | **D** |
| ACER | TravelMate C301XCi, C301XCi Tablet PC Series | **Green(19V)** | **D** |
| ACER | TravelMate C302, C302XCi, C302XMi, C302XMib Tablet PC Series | **Green(19V)** | **D** |
| ACER | TravelMate C303, C303XMi Tablet PC Series | **Green(19V)** | **D** |
| APPLE | iBook 500MHz G3 processor or higher | **Orange(24V)** | **Q** |
| APPLE | iBook G3 | **Orange(24V)** | **G** |
| APPLE | iBook G4 | **Orange(24V)** | **Q** |
| APPLE | Power Book 1400, 2400, 3400 Series | **Orange(24V)** | **G** |
| APPLE | Power Book G3 | **Orange(24V)** | **G** |
| APPLE | Power Book G4 | **Orange(24V)** | **Q** |
| ASUS | A1000 Series | **Green(19V)** | **E** |
| ASUS | A8F, A8Fm, A8H, A8He, A8Jc, A8Je, A8Jn, A8Jr, A8Js, A8M, A8Sc, A8Sr, A8Tc | **Green(19V)** | **C** |
| ASUS | ArtBook L7336 | **Green(19V)** | **E** |
| ASUS | B1000 Series | **Green(19V)** | **E** |
| ASUS | F3H, F3M, F3Ja, F3Jc, F3Jp, F3Jr, F3Sc, F3 Sv, F3Tc | **Green(19V)** | **C** |
| ASUS | F5R, F5V | **Green(19V)** | **C** |
| ASUS | F7000, 7400 | **Green(19V)** | **E** |
| ASUS | F8Sa, F8Sv | **Green(19V)** | **C** |
| ASUS | F9E, F9F, F9J, F9S | **Green(19V)** | **C** |
| ASUS | G1, G1S | **Green(19V)** | **C** |
| ASUS | L1000B Series | **Green(19V)** | **E** |
| ASUS | L2000B, L2000D, L2000E, L2000C, L2000S Series | **Green(19V)** | **E** |
| ASUS | L7000, L7000C, L7200, L7300 | **Green(19V)** | **E** |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| ASUS | L8400 | Green(19V) | E |
| ASUS | M1000 Series | Green(19V) | E |
| ASUS | M2 Series | Green(19V) | E |
| ASUS | M2000, M2400 Series | Green(19V) | E |
| ASUS | MP 8xxx Series | Green(19V) | E |
| ASUS | S1000 Series | Green(19V) | E |
| ASUS | S6Fm | Green(19V) | C |
| ASUS | T4700CS | Green(19V) | E |
| ASUS | T7200 | Green(19V) | E |
| ASUS | T9000 Series | Green(19V) | E |
| ASUS | U5F | Green(19V) | C |
| ASUS | V2Je | Green(19V) | C |
| ASUS | X80H | Green(19V) | C |
| ASUS | Z35H, Z35L, Z53Jc | Green(19V) | C |
| COMPAQ | 100s Series | Green(19V) | B |
| COMPAQ | 2510p | Green(19V) | S |
| COMPAQ | 6510b | Green(19V) | S |
| COMPAQ | Aero 8000 | Purple(15V) | E |
| COMPAQ | Armada 100 | Green(19V) | E |
| COMPAQ | Armada 110 | Green(19V) | E |
| COMPAQ | Armada 1100 Series | Green(19V) | E |
| COMPAQ | Armada 4100 Series | Green(19V) | E |
| COMPAQ | Armada 4200 Series | Green(19V) | E |
| COMPAQ | Armada E500, E700 Series | Green(19V) | E |
| COMPAQ | Armada M300, M700 Series | Green(19V) | E |
| COMPAQ | Armada V300 Series | Green(19V) | E |
| COMPAQ | Evo N1000, N1000C, N1000V, N1015V, N1020V Series | Green(19V) | E |
| COMPAQ | Evo N105 Series | Green(19V) | C |
| COMPAQ | Evo N110 Series | Green(19V) | E |
| COMPAQ | Evo N115 Series | Green(19V) | C |
| COMPAQ | Evo N150 Series | Green(19V) | E |
| COMPAQ | Evo N160, N180 Series | Green(19V) | C |
| COMPAQ | Evo N200 Series | Green(19V) | E |
| COMPAQ | Evo N400c, N410c | Green(19V) | E |
| COMPAQ | Evo N600c, N610c, N620c | Green(19V) | E |
| COMPAQ | Evo N800 Series | Green(19V) | E |
| COMPAQ | LTE 5000, 6000 Series | Green(19V) | D |
| COMPAQ | nc4000, nc4010, nc6000, nc8000 | Green(19V) | E |
| COMPAQ | nc6400 | Green(19V) | S |
| COMPAQ | Notebook 100 | Green(19V) | B |
| COMPAQ | nr3600 | Green(19V) | E |
| COMPAQ | nw8000 | Green(19V) | E |
| COMPAQ | nx5000, nx7000, nx7010 | Green(19V) | E |
| COMPAQ | nx9005, 9008, 9010 | Green(19V) | E |
| COMPAQ | nx9110 | Green(19V) | E |
| COMPAQ | Presario 1000 Series | Green(19V) | C |
| COMPAQ | Presario 1200 Series | Green(19V) | C |
| COMPAQ | Presario 12XL, 14XL, 16XL, 17XL, 18XL | Green(19V) | C |
| COMPAQ | Presario 1400 Series | Green(19V) | C |
| COMPAQ | Presario 1500 Series | Green(19V) | E |
| COMPAQ | Presario 1600, 1600i Series | Green(19V) | C |
| COMPAQ | Presario 1700 Series | Green(19V) | C |
| COMPAQ | Presario 1800, 1800t Series | Green(19V) | C |
| COMPAQ | Presario 2100, 2100Z Series | Green(19V) | C |
| COMPAQ | Presario 2500 Series | Green(19V) | C |
| COMPAQ | Presario 2700 Series | Green(19V) | C |
| COMPAQ | Presario 2800 Series | Green(19V) | E |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| COMPAQ | Presario 2900 Series | Green(19V) | E |
| COMPAQ | Presario 300 Series | Green(19V) | E |
| COMPAQ | Presario 3000 Series | Green(19V) | C |
| COMPAQ | Presario 700, 800 Series | Green(19V) | C |
| COMPAQ | Presario 900 Series | Green(19V) | E |
| COMPAQ | Presario B1200 | Green(19V) | S |
| COMPAQ | Presario X1000, X1001 Series | Green(19V) | E |
| COMPAQ | Prosignia 150 | Green(19V) | C |
| COMPAQ | Prosignia 170, 190 Series | Green(19V) | E |
| COMPAQ | Tablet PC TC-1000, TC-1100 | Green(19V) | E |
| DELL | Inspiron 1150 | Black(20V) | K |
| DELL | Inspiron 2000, 2100 | Black(20V) | O |
| DELL | Inspiron 2500, 2600, 2650 | Black(20V) | F |
| DELL | Inspiron 3000, 3200, 3500 | Green(19V) | C |
| DELL | Inspiron 300m | Black(20V) | K |
| DELL | Inspiron 3700, 3800 | Black(20V) | F |
| DELL | Inspiron 4000, 4100, 4150, 4200 | Black(20V) | F |
| DELL | Inspiron 5000, 5100 | Black(20V) | F |
| DELL | Inspiron 7000 | Green(19V) | C |
| DELL | Inspiron 7500, 8000, 8100 | Black(20V) | F |
| DELL | Inspiron 8200 | Black(20V) | F |
| DELL | Inspiron 8500, 8600, 300m, 400m, 500m, 600m | Black(20V) | K |
| DELL | Latitude 450MC Series | Green(19V) | C |
| DELL | Latitude C400, C410 Series | Black(20V) | F |
| DELL | Latitude C500, C510 Series | Black(20V) | F |
| DELL | Latitude C600, C610 Series | Black(20V) | F |
| DELL | Latitude C640, C840 | Black(20V) | F |
| DELL | Latitude C800, C810 Series | Black(20V) | F |
| DELL | Latitude CP Series | Black(20V) | F |
| DELL | Latitude CPi Series, CPi 300ST, CPi 300XT, CPi 366XT, Cpi A400XT | Black(20V) | F |
| DELL | Latitude CPt Series | Black(20V) | F |
| DELL | Latitude CPx Series, CPx H500GT | Black(20V) | F |
| DELL | Latitude CS/CSx Series | Black(20V) | F |
| DELL | Latitude D400, D500, D505, D600, D800, X300 and the M60 | Black(20V) | K |
| DELL | Latitude L400, L600, L800 Series | Black(20V) | O |
| DELL | Latitude LM | Black(20V) | F |
| DELL | Latitude LS Series | Green(19V) | O |
| DELL | Latitude LSH 400 | Green(19V) | O |
| DELL | Latitude M40 workstation | Black(20V) | F |
| DELL | Latitude X200 | Black(20V) | F |
| DELL | Latitude XP 4100 Series | Green(19V) | A |
| DELL | Latitude XPi Series | Green(19V) | F |
| DELL | Precision M50 | Black(20V) | F |
| DELL | SmartStep 200 & 250 computers | Green(19V) | D |
| FUJITSU | FMV-BIBLO FLX2H | Blue(16V) | A |
| FUJITSU | FMV-BIBLO LOOX S80B, S80B/W, S80C, S80C/W | Blue(16V) | A |
| FUJITSU | FMV-BIBLO MG12B, MG12B/C, MG12B/M, MG12C, MG12C/M, MG12D, MG13D, MG17D/A | Blue(16V) | A |
| FUJITSU | FMV-BIBLO MG50E, MG55E, MG70E, MG70E/ST, MG75E | Blue(16V) | A |
| FUJITSU | FMV-BIBLO MR16B | Blue(16V) | A |
| FUJITSU | FMV-BIBLO NB14B, NB14B/R, NB15B, NB15B/S, NB15B/T, NB16B, NB16B/M, NB16C, NB16C/ST, NB16C/T, NB16C/V, NB16CA, NB16CR | Blue(16V) | A |
| FUJITSU | FMV-BIBLO NB18B, NB18C, NB18C/T, NB18D, NB18D/D, NB18D/F, NB18D/L, NB18D/V, NB19D, NB19D/D | Blue(16V) | A |
| FUJITSU | FMV-BIBLO NB70E, NB70E/T | Blue(16V) | A |
| FUJITSU | FMV-BIBLO NH24C, NH24D, NH26C, NH28D, NH50E, NH70E, NH90E/T | Blue(16V) | A |
| FUJITSU | FMV-BIBLO NU | Blue(16V) | A |
| FUJITSU | FMV-BIBLO RS18D, RS18D/D, RS18D/ST, RS18D/T, RS50E/T, RS55E/T | Blue(16V) | A |
| FUJITSU | FMV-BIBLO T50E, T50E/W, T70E, T93B, T93B/W, T93C, T93C/W | Blue(16V) | A |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| FUJITSU | LifeBook 200, 270Dx, 280Dx | Blue(16V) | A |
| FUJITSU | LifeBook 400, 420Dx, 435Dx | Blue(16V) | A |
| FUJITSU | Lifebook 500, 531T, 535T, 555Tx, 565Tx, 585Tx, 585Tx1 | Blue(16V) | A |
| FUJITSU | LifeBook 600, 635T, 635Tx, 635Tx1, 655Tx, 656Tx, 656Tx1, 675Tx, 690Tx | Blue(16V) | A |
| FUJITSU | LifeBook 700, 735Dx, 755Tx, 756Dx, 765Tx, 770Tx, 790Tx | Blue(16V) | A |
| FUJITSU | LifeBook 900, 985Tx, 990Tx2 | Blue(16V) | A |
| FUJITSU | LifeBook A1010 | Green(19V) | C |
| FUJITSU | LifeBook A4170 | Blue(16V) | A |
| FUJITSU | LifeBook B112, B142 | Blue(16V) | A |
| FUJITSU | LifeBook B2 | Blue(16V) | A |
| FUJITSU | LifeBook B2130, B2131, B2545, B2562, B2566, B2610, B2620, B2630 | Blue(16V) | A |
| FUJITSU | LifeBook B3010D | Blue(16V) | A |
| FUJITSU | LifeBook C2010, C2110, C2210, 2211 | Green(19V) | C |
| FUJITSU | LifeBook C340, C350, C352, C353, C360 | Blue(16V) | A |
| FUJITSU | LifeBook C4120, C4235, C5130, C5235 | Blue(16V) | A |
| FUJITSU | LifeBook C6177, C6320, C6330 | Blue(16V) | A |
| FUJITSU | LifeBook C6525, C6535, C6537, C6547, C6556, C6557, C6577, C6581, C6591 | Blue(16V) | A |
| FUJITSU | LifeBook C6611, C6631, C6651 | Blue(16V) | A |
| FUJITSU | LifeBook C7631, C7651, C7661 | Blue(16V) | A |
| FUJITSU | LifeBook Celsius Mobile H | Blue(16V) | A |
| FUJITSU | Lifebook E2010 | Blue(16V) | A |
| FUJITSU | LifeBook E330, E340, E342, E350, E351, E360, E362, E370, E380 | Blue(16V) | A |
| FUJITSU | LifeBook E4010, E4010D | Green(19V) | C |
| FUJITSU | LifeBook E5140, E5320, E5520 | Blue(16V) | A |
| FUJITSU | Lifebook E6150, E6520, E6530, E6540, E6541, E6550, E6555, E6556, E6570, E6571, E6575, | Blue(16V) | A |
| FUJITSU | LifeBook E6624, E6634, E6644, E6654, E6664 | Green(19V) | C |
| FUJITSU | LifeBook E7010, E7110 | Green(19V) | C |
| FUJITSU | LifeBook L2010, L2020 | Green(19V) | C |
| FUJITSU | LifeBook L440, L470 | Blue(16V) | A |
| FUJITSU | LifeBook P1000, P1032, P1035, P1120 | Blue(16V) | A |
| FUJITSU | LifeBook P2000, P2040, P2046 | Blue(16V) | A |
| FUJITSU | LifeBook P2110, P2120 | Blue(16V) | A |
| FUJITSU | LifeBook P5010, P5010D, P5020, P5020D | Blue(16V) | A |
| FUJITSU | LifeBook S2010, S2020 | Blue(16V) | A |
| FUJITSU | LifeBook S4510, S4542, S4546, S4572 | Blue(16V) | A |
| FUJITSU | LifeBook S5582 | Blue(16V) | A |
| FUJITSU | LifeBook S6010, S6110, S6120, S6120D, S6210 | Blue(16V) | A |
| FUJITSU | LifeBook S700, S700D, | Blue(16V) | A |
| FUJITSU | LifeBook Stylistic 1200, 2300, 3400, 3500 | Blue(16V) | A |
| FUJITSU | LifeBook Stylistic LT C-500, LT P-600 | Blue(16V) | A |
| FUJITSU | LifeBook X7595 | Blue(16V) | A |
| FUJITSU | LifeBookStylistic ST4110, ST4110P, ST4120, ST4120P, ST4121 | Blue(16V) | A |
| FUJITSU | LifeBookStylistic ST5010, ST5010D, ST5011, ST5011D Tablet PC | Blue(16V) | A |
| FUJITSU | LifeBookStylistic T3000, T3000D, T3010, T3010D Tablet PC | Blue(16V) | A |
| FUJITSU | Point 510, 1600 | Blue(16V) | A |
| GATEWAY | 400SD4, 400VTX, 400SP, 400SP plus | Green(19V) | C |
| GATEWAY | 450L & 600L series | Green(19V) | C |
| GATEWAY | 450ROG, 450SX4, 450X, 450XL | Green(19V) | C |
| GATEWAY | 600YG2, 600YGR | Green(19V) | C |
| GATEWAY | M305, M305X | Green(19V) | C |
| GATEWAY | M350, M675 | Green(19V) | C |
| GATEWAY | M405CS, M405X | Green(19V) | C |
| GATEWAY | M500, M505X, M505XL | Green(19V) | C |
| GATEWAY | Solo 1100, 1150 Series | Green(19V) | D |
| GATEWAY | Solo 1200 Series | Green(19V) | D |
| GATEWAY | Solo 1400, 1450 Series | Green(19V) | D |
| GATEWAY | Solo 2100, 2150 Series | Green(19V) | D |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| GATEWAY | Solo 2200 Series | Green(19V) | D |
| GATEWAY | Solo 2300 Series | Green(19V) | D |
| GATEWAY | Solo 2500, 2550 Series | Green(19V) | D |
| GATEWAY | Solo 3100, 3150 Series | Green(19V) | D |
| GATEWAY | Solo 3300, 3350 Series | Green(19V) | O |
| GATEWAY | Solo 5100, 5150 Series | Green(19V) | D |
| GATEWAY | Solo 5300, 5350 Series | Green(19V) | D |
| GATEWAY | Solo 600 Series | Green(19V) | D |
| GATEWAY | Solo 9100, 9150 Series | Green(19V) | D |
| GATEWAY | Solo 9300 Series | Green(19V) | D |
| GATEWAY | Solo 9500, 9550 Series | Green(19V) | D |
| GATEWAY | Tablet PC, Tablet PC deluxe | Green(19V) | C |
| HEWLETT PACKARD | Deskjet 450 Printer | Green(19V) | D |
| HEWLETT PACKARD | OmniBook 2000, 2100, 2103, 2105 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 300, 425, 430, 500, 510, 530, 600c, 600ct, 900, 900b | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 3000, 3100, 3101 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 4000, 4100, 4101, 4103, 4105, 4150 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 5000, 5500, 5700 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 6000, 6100 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook 7100, 7103, 7150 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook vt Series, vt6200 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook XE, XE2, XE3 Series | Green(19V) | C |
| HEWLETT PACKARD | OmniBook xe4100, xe4200, xe4400, xe4500 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook xt Series, xt1000, xt1500 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook xt6050, xt6200 | Green(19V) | C |
| HEWLETT PACKARD | OmniBook zt1000, zt1500 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion 2105, 3101, 4101, 4103, 4105, 5159 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion 5100, 5200, 5400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion N3100, N3200, N3300, N3400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion N5100, N5200, N5300, N5400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion N6100, N6300, N6400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xf125, xf145, xf235, xf255, xf315, xf325, xf328, xf335 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xh136, xh156, xh176, xh215, xh216, xh226, xh355, xh365 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xh455, xh485, xh535, xh545, xh555, xh575, xh675 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xt115, xt118, xt125, xt128, xt155, xt178, xt183, xt188 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xt236, xt276, xt345, xt375, xt395, xt412 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xt512, xt537, xt545, xt555, xt565, xt575, xt585, xt595 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xt5300, xt5366 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xt5377 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xu155 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion xz133, xz148, xz163, xz168, xz185, xz275, xz295, xz335, xz355 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion ze1000, ze1100, ze1200 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion ze4000, ze4100, ze4200, ze4300 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion ze4400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion ze5000, ze5100, ze5200, ze5300, ze5400 Series | Green(19V) | C |
| HEWLETT PACKARD | Pavilion zt Series, zt3000 | Green(19V) | C |
| HEWLETT PACKARD | Pavilion zu Series | Green(19V) | C |
| HEWLETT PACKARD | Tablet PC tr3000 | Green(19V) | C |
| HITACHI | Vision Book 133 | Blue(16V) | C |
| HITACHI | Vision Book 4000 | Blue(16V) | C |
| HITACHI | Vision Book 5000 | Green(19V) | D |
| HITACHI | Vision Book E & MX series | Green(19V) | D |
| HITACHI | Vision Book Elite 8000, 8560 Series | Green(19V) | D |
| HITACHI | Vision Book Plus 4100, 4140, 4150 | Blue(16V) | C |
| HITACHI | Vision Book Plus 5000 Series | Green(19V) | D |
| HITACHI | Vision Book Pro 6000 Series | Green(19V) | C |
| HITACHI | Vision Book Pro 7000 Series | Green(19V) | C |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| HP | Pavilion dv2000, dv2100, dv2200 | Green(19V) | E |
| HP | Pavilion dv6000, dv6100, dv6200, dv6500, dv6600 | Green(19V) | E |
| HP | Pavilion tx1100, tx1306 | Green(19V) | E |
| IBM | Thinkpad "A" Series | Blue(16V) | C |
| IBM | Thinkpad "R" Series | Blue(16V) | C |
| IBM | Thinkpad "T" Series | Blue(16V) | C |
| IBM | Thinkpad "X" Series | Blue(16V) | C |
| IBM | Thinkpad 240, 240X | Blue(16V) | C |
| IBM | Thinkpad 290 | Blue(16V) | C |
| IBM | Thinkpad 310, 310D, 310E, 310ED | Green(19V) | D |
| IBM | Thinkpad 355, 360 | Blue(16V) | H |
| IBM | Thinkpad 365, 365XD | Blue(16V) | C |
| IBM | Thinkpad 380, 380D, 380E, 380ED, 380XD, 380Z | Blue(16V) | C |
| IBM | Thinkpad 385, 385D, 385ED, 385XD | Blue(16V) | C |
| IBM | Thinkpad 390, 390E, 390X | Blue(16V) | C |
| IBM | Thinkpad 560, 560E, 560X, 560Z | Blue(16V) | C |
| IBM | Thinkpad 570 | Blue(16V) | C |
| IBM | Thinkpad 600, 600E, 600X | Blue(16V) | C |
| IBM | Thinkpad 700, 720, 750, 755 | Blue(16V) | H |
| IBM | Thinkpad 760, 765 | Blue(16V) | C |
| IBM | Thinkpad 770, 770E, 770ED, 770X, 770Z | Blue(16V) | C |
| IBM | Thinkpad i1200 | Blue(16V) | C |
| IBM | Thinkpad i1300 | Blue(16V) | C |
| IBM | Thinkpad i1400-2611 | Green(19V) | D |
| IBM | Thinkpad i1400-2621 | Blue(16V) | C |
| IBM | Thinkpad i1500-2611 | Green(19V) | D |
| IBM | Thinkpad i1500-2621 | Blue(16V) | C |
| IBM | Thinkpad i1720, i1721 | Blue(16V) | C |
| IBM | Thinkpad TransNote | Blue(16V) | C |
| IBM | Workpad Z50 | Green(19V) | D |
| NEC | Ready 120T | Purple(15V) | D |
| NEC | Ready 220T, 230T, 330T, 340T, 360T, 440T | Green(19V) | C |
| NEC | Versa 2000 series, 2000C and 2000D | Green(19V) | C |
| NEC | Versa 2200 series, 2200C, 2205C | Green(19V) | C |
| NEC | Versa 2400, 2500, 2500CD, 2505, 2530 | Green(19V) | C |
| NEC | Versa 500, 550D | Green(19V) | C |
| NEC | Versa 5000, 5030, 5060, 5060X, 5080, 5080X | Green(19V) | C |
| NEC | Versa 6000 Series, 60101H, 6030H, 6030X, 6050MH, 6050MX, 6050MT, 6060 | Green(19V) | B |
| NEC | Versa 6200 series, 6200MX, 6200NT, 6220, 6230, 6260 | Green(19V) | B |
| NEC | Versa C140, C150, C160 | Green(19V) | C |
| NEC | Versa C320 | Green(19V) | C |
| NEC | Versa Daylight 120 | Green(19V) | C |
| NEC | Versa E120 | Green(19V) | C |
| NEC | Versa FM320, FM500, FP520, FS800 | Green(19V) | C |
| NEC | Versa Fx | Purple(15V) | B |
| NEC | Versa Fxi | Blue(16V) | B |
| NEC | Versa IGO3000, IGO5000, IGO6000 | Green(19V) | C |
| NEC | Versa L320 | Green(19V) | C |
| NEC | Versa Litepad 933 | Green(19V) | C |
| NEC | Versa LX, LXi Series | Purple(15V) | B |
| NEC | Versa M300, M320, M3210, M500 | Green(19V) | C |
| NEC | Versa P440, P520, P600, P700 | Green(19V) | C |
| NEC | Versa S800, S820, T400, | Green(19V) | C |
| NEC | Versa SX Series | Purple(15V) | B |
| NEC | Versa Sxi Series | Green(19V) | C |
| NEC | Versa Txi Series | Purple(15V) | B |
| NEC | Versa VX, VXi Series | Green(19V) | C |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| PANASONIC | Toughbook CF01 | Blue(16V) | A |
| PANASONIC | Toughbook CF11 | Blue(16V) | A |
| PANASONIC | Toughbook CF17 | Blue(16V) | A |
| PANASONIC | Toughbook CF170, CF270 | Blue(16V) | A |
| PANASONIC | Toughbook CF18 | Blue(16V) | C |
| PANASONIC | Toughbook CF25, CF27, CF28 | Blue(16V) | A |
| PANASONIC | Toughbook CF29 | Blue(16V) | C |
| PANASONIC | Toughbook CF33, CF34, CF35, CF37 | Blue(16V) | A |
| PANASONIC | Toughbook CF370, CF380 | Blue(16V) | A |
| PANASONIC | Toughbook CF41, CF45, CF47 | Blue(16V) | A |
| PANASONIC | Toughbook CF48, CF50, CF51 | Blue(16V) | C |
| PANASONIC | Toughbook CF61, CF62, CF63 | Blue(16V) | A |
| PANASONIC | Toughbook CF71 | Blue(16V) | A |
| PANASONIC | Toughbook CF72, CF73 | Blue(16V) | C |
| PANASONIC | Toughbook CF-M34 | Blue(16V) | A |
| PANASONIC | Toughbook CF-V21, CF-V21P | Green(19V) | A |
| PANASONIC | Toughbook CF-V25, CF-V41 | Blue(16V) | A |
| PANASONIC | Toughbook R1, T1, T2, W2, Y2 | Blue(16V) | C |
| SAMSUNG | GT8000 | Green(19V) | I |
| SAMSUNG | NoteMaster 486C/25 | Purple(15V) | B |
| SAMSUNG | Note-PC | Green(19V) | I |
| SAMSUNG | NP30 | Green(19V) | I |
| SAMSUNG | NX05, NX10, NX15, NX30 | Green(19V) | I |
| SAMSUNG | ProSens 500, 505, 520, 521, 525 | Black(20V) | A |
| SAMSUNG | Sens 500 | Black(20V) | A |
| SAMSUNG | Sens 700, 800 | Blue(16V) | A |
| SAMSUNG | Sens 810 | Black(20V) | A |
| SHARP | PC3010, PC3020 | Green(19V) | C |
| SHARP | PC3030, PC3040 | Green(19V) | D |
| SHARP | PC3050, PC3060 | Green(19V) | C |
| SHARP | PC3070, PC3080 | Green(19V) | D |
| SHARP | PC3150 | Green(19V) | C |
| SHARP | PC8700, PC8800, PC8900, PC9010, PC9020, PC9030,PC9050, PC9080, PC9340T, PC-S400 | Green(19V) | D |
| SONY | Picturebook C1X | Blue(16V) | A |
| SONY | VAIO 700-748 Series | Green(19V) | A |
| SONY | VAIO 800-838 Series (Not OEM) | Green(19V) | A |
| SONY | VAIO 81 | Green(19V) | A |
| SONY | VAIO A130/A130P, A170/A170P, A190 | Green(19V) | A |
| SONY | VAIO C1MHP, C1MV, C1MV/C, C1MVM/C, C1MVP, C1MVP/C, C1MW, C1VG, C1VXS Series | Blue(16V) | A |
| SONY | VAIO C1X Series(Not OEM) | Blue(16V) | A |
| SONY | VAIO F, FR, FX, FXA Series | Green(19V) | A |
| SONY | VAIO FRV, GRT Series | Green(19V) | A |
| SONY | VAIO GR Series | Blue(16V) | A |
| SONY | VAIO GRS, GRX Series | Green(19V) | A |
| SONY | VAIO GRT250, GRT270G | Green(19V) | A |
| SONY | VAIO GRT390Z | Green(19V) | A |
| SONY | VAIO GRV Series | Green(19V) | A |
| SONY | VAIO GRZ Series | Green(19V) | A |
| SONY | VAIO GX Series | Green(19V) | A |
| SONY | VAIO K12P, K13, k15, K17 | Green(19V) | A |
| SONY | VAIO NV, NVR Series | Green(19V) | A |
| SONY | VAIO PG32 | Green(19V) | A |
| SONY | VAIO QR Series, QR10, QR20 | Green(19V) | A |
| SONY | VAIO R500, R505, R600 Series | Green(19V) | A |
| SONY | VAIO SR, SRX Series | Blue(16V) | A |
| SONY | VAIO TR1, TR2 Series | Blue(16V) | A |
| SONY | VAIO TR3 Series, TR3A, TR3AP1, TR3AP2, TR3AP3 | Blue(16V) | A |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| SONY | VAIO V505, V505A, V505AC, V505ACK, V505ACP, V505AK, V505AP, V505AX, V505AXP | **Blue(16V)** | **A** |
| SONY | VAIO V505B, V505BC, V505BX, V505BXP, V505D, V505DC1, V505DC11, V505DC1P7, V505DX, V505DXP | **Blue(16V)** | **A** |
| SONY | VAIO V505EC, V505EX, V505P, V505PB, V505R | **Blue(16V)** | **A** |
| SONY | VAIO VX Series, VX71P | **Blue(16V)** | **A** |
| SONY | VAIO X9, X18, X29 | **Green(19V)** | **A** |
| SONY | VAIO XE7, XE17 | **Green(19V)** | **A** |
| SONY | VAIO XG Series | **Green(19V)** | **A** |
| SONY | VAIO Z1, Z1A, Z1A1, Z1AP1, Z1AP2, Z1AP3, Z1M, Z1R5P, Z1RA, Z1RAP1, Z1RAP2, Z1RAP3, Z1SP, Z1VA, Z1VAP1, Z1VAP2 | **Blue(16V)** | **A** |
| SONY | VAIO Z1, Z1WA, Z1WAP, Z1WAMP1, Z1WAMP2, Z1WAMP3 | **Blue(16V)** | **A** |
| SONY | VAIO Z505, Z505FA, Z505GA, Z505GAH, Z505GAM, Z505HE, Z505HS, Z505HSK, Z505JE, Z505JEK, Z505JS, Z505JSK, Z505LE, Z505LEK, Z505LS, Z505LSK, Z505R, Z505RX, Z505S, Z505SX | **Green(19V)** | **A** |
| SONY | VAIO Z505AX, Z505AXP | **Blue(16V)** | **A** |
| SONY | VAIO Z600HEK, Z600LEK, Z600NE, Z600NEK, Z600RE, Z600TEK | **Green(19V)** | **A** |
| TOSHIBA | Libretto 100, 110 | **Purple(15V)** | **P** |
| TOSHIBA | Libretto 20CT, 50CT, 70CT | **Purple(15V)** | **B** |
| TOSHIBA | Libretto 50, 70 | **Purple(15V)** | **P** |
| TOSHIBA | Portege 120 | **Purple(15V)** | **B** |
| TOSHIBA | Portege 2000, 2010 Series | **Purple(15V)** | **B** |
| TOSHIBA | Portege 300CT, 310CT, 320CT | **Purple(15V)** | **B** |
| TOSHIBA | Portege 3010, 3015, 3020, 3025 | **Purple(15V)** | **P** |
| TOSHIBA | Portege 3110, 3120 | **Purple(15V)** | **P** |
| TOSHIBA | Portege 3440, 3480, 3490CDT, 3490CT | **Purple(15V)** | **P** |
| TOSHIBA | Portege 3500 Tablet, 3505 Tablet | **Purple(15V)** | **B** |
| TOSHIBA | Portege 4000, 4005, 4010 Series | **Purple(15V)** | **B** |
| TOSHIBA | Portege 610CT, 620CT, 635CT, 650CT, 660CT | **Purple(15V)** | **B** |
| TOSHIBA | Portege 7000, 7100, 7200 Series | **Purple(15V)** | **B** |
| TOSHIBA | Portege M100, M200 | **Purple(15V)** | **B** |
| TOSHIBA | Portege R100 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 1000, 1005 Series | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1100 | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1110, 1115, 1130, 1135 Series | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1200 | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1400, 1405, 1410, 1415 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 1500 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 1555 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 1600, 1605 Series | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1615 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 1625, 1675, 1695 | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1700, 1715, 1730, 1735, 1750, 1755 Series | **Green(19V)** | **C** |
| TOSHIBA | Satellite 1800, 1805 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2000, 2060, 2065, 2095 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2100, 2105, 2140, 2180 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 210CS | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 220, 225, 230CX | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2210, 2250 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2400, 2405, 2410, 2415 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2430, 2435 | **Green(19V)** | **C** |
| TOSHIBA | Satellite 2450, 2455 | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2500, 2505, 2510, 2515, 2520, 2525, 2530, 2535, 2540, 2545, 2590, 2595 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2600, 2610, 2615, 2650XDVD, 2655, 2675, 2695 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2700, 2715, 2755, 2775 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 2800, 2805 Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 300, 305, 310, 315 CDT and CDS Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 3000, 3005 Series | **Green(19V)** | **C** |
| TOSHIBA | Satellite 320, 330, 325, 330, 335 CDT and CDS Series | **Purple(15V)** | **B** |
| TOSHIBA | Satellite 4000, 4005, 4010, 4015, 4020, 4025, 4030, 4060, 4070, 4080, 4085, 4090 Series | **Purple(15V)** | **B** |

# Vivanco Notebook Power Supplies (EDP 23685/23686) Compatibility List December 2008

| Brand Name | Model Number | Voltage Device | Tip No. |
|---|---|---|---|
| TOSHIBA | Satellite 4100, 4200, 4300, 4600 Series | Purple(15V) | B |
| TOSHIBA | Satellite 5000, 5005 Series | Purple(15V) | B |
| TOSHIBA | Satellite 5100, 5105 Series | Purple(15V) | B |
| TOSHIBA | Satellite 5200, 5205 Series | Purple(15V) | B |
| TOSHIBA | Satellite A10, A15 | Purple(15V) | B |
| TOSHIBA | Satellite A35 Series | Green(19V) | C |
| TOSHIBA | Satellite A60-S1561, A60-S156 | Green(19V) | C |
| TOSHIBA | Satellite A60-S166 | Green(19V) | C |
| TOSHIBA | Satellite A70 | Green(19V) | C |
| TOSHIBA | Satellite A75 | Green(19V) | C |
| TOSHIBA | Satellite M20, M30, M35 | Purple(15V) | B |
| TOSHIBA | Satellite P10, P15, P25 Series | Green(19V) | B |
| TOSHIBA | Satellite Pro 4200, 4220, 4260, 4280 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 4300 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 440, 445, 460 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 4600 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 465 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 470, 480, 490 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro 5000 | Purple(15V) | B |
| TOSHIBA | Satellite Pro 6000, 6100 Series | Purple(15V) | B |
| TOSHIBA | Satellite Pro M10, M15 | Purple(15V) | B |
| TOSHIBA | Satellite1900, 1905, 1955 Series | Green(19V) | C |
| TOSHIBA | T1900C, T1910CS, T1950CS, T1950CT | Green(19V) | D |
| TOSHIBA | T200 | Purple(15V) | B |
| TOSHIBA | T2400 | Green(19V) | D |
| TOSHIBA | T3400C, T3400CT, T3440CT, T3480CT, T3490CT | Purple(15V) | B |
| TOSHIBA | T3600C, T3600CT | Purple(15V) | B |
| TOSHIBA | T4500, T4600, T4700, T4800, T4850, T4900 | Green(19V) | D |
| TOSHIBA | Tecra 510CDT | Purple(15V) | B |
| TOSHIBA | Tecra 520, 520CDS/CDT | Purple(15V) | B |
| TOSHIBA | Tecra 530, 530CDS/CDT | Purple(15V) | B |
| TOSHIBA | Tecra 550, 550CDT | Purple(15V) | B |
| TOSHIBA | Tecra 700, 700CS, 700CT, 700CDT | Purple(15V) | B |
| TOSHIBA | Tecra 710, 710CDT | Purple(15V) | B |
| TOSHIBA | Tecra 720, 720CDT | Purple(15V) | B |
| TOSHIBA | Tecra 730, 730CDT, 730CS, 730XCDT | Purple(15V) | B |
| TOSHIBA | Tecra 740, 740CDT | Purple(15V) | B |
| TOSHIBA | Tecra 750, 750CD, 750CDM, 750CDS, 750CDT, 750DVD | Purple(15V) | B |
| TOSHIBA | Tecra 780, 780CDM, 780CDT, 780CDV, 780DVD | Purple(15V) | B |
| TOSHIBA | Tecra 8000, 8100, 8200 | Purple(15V) | B |
| TOSHIBA | Tecra 9000, 9100 | Purple(15V) | B |
| TOSHIBA | Tecra A1, M1, M2, M2V, S1 | Purple(15V) | B |
| TOSHIBA | Tecra TE2100 Series | Purple(15V) | B |
| VIEWSONIC | Viewpad 100 Super PDA computers | Green(19V) | C |
| VIEWSONIC | Viewpad 1000 Tablet PC | Blue(16V) | C |
| VIEWSONIC | Viewpad V1250, V1250S Tablet PC | Black(20V) | C |
| WINBOOK | Winbook CJ | Green(19V) | C |
| WINBOOK | Winbook FX | Green(19V) | D |
| WINBOOK | Winbook J1 | Green(19V) | C |
| WINBOOK | Winbook J4, M Series | Green(19V) | C |
| WINBOOK | Winbook N Series | Green(19V) | C |
| WINBOOK | Winbook Si Series, Si2 | Green(19V) | C |
| WINBOOK | Winbook X Series X1, X2, X4 | Green(19V) | C |
| WINBOOK | Winbook XL, XLi Series | Green(19V) | C |
| WINBOOK | Winbook XP, XP5, XP5Pro Series | Green(19V) | C |
| WINBOOK | Winbook Z Series | Green(19V) | C |